

555 E. Main Street, P.O. Box 430, Russia, Ohio 45363


Phone (937)526-4065 Fax (937)526-3904

Email: info@superioraluminum.com

## Stair and Ramp Measuring for Railing

- 1. Take a picture(s) of the stair(s) or ramp(s) you intend to add railing to.
- 2. Print the picture(s)
- Measure the relevant areas using the guides below. Mark the associated image accordingly
- 4. Send the marked up picture(s) to Superior Aluminum with all relevant details. This removes the need for a sketch and can help alleviate potential future questions. Use the image on the right as an example
- \*If you do not have the capabilities to take and print a photo, please draw a simple sketch and proceed with steps 3 and 4.





- 1. The tread and riser of each step
- 2. The overall nose to nose dimension of the steps
- 3. Any supplemental measurements applicable to your project

## **Required Ramp Information**

- 1. The length of ramp on angle
- 2. Total rise of ramp OR angle of ramp

## Additional Required Details

- 1. Railing Series
- 2. Railing Color
- 3. Railing style if preference is different than standard two-line railing

